

MODEL			ISSUE	SPEC	
iPhone X Silver 64GB	AB	353055099460153	White spot on screen,no Face ID	US	110
iPhone X Silver 64GB	BC	356719089464890	Broken lens,ghost display	US	110
iPhone X Silver 64GB	AB	354850098967383	No Face ID, green line on screen	US	132
iPhone X Silver 256GB	AB	356727089860405	Rear glass camera,bad screen	US	137,5
iPhone XS Space Gray 64GB	AB	353145102183049	Tactile	US	137,5
iPhone XS Gold 64GB	AB	357209096393380	Touch	US	121
iPhone XR Blue 64GB	AB/A+	357343095700582	Battery message	US	121
iPhone XR Blue 64GB	AB	353064105754229	No Face ID	US	121
iPhone XR White 64GB	AB	353054102696119	Broken display,broken camera glass/dirty front camera	US	121
iPhone XR WHITE 64GB	AB/LCD A+	357376098542213	CAN'T BE ACTIVATED	US	121
iPhone XR Blue 64GB	AB/lcd A+	357378094145389	does not read sim card	US	121
iphone XR Coral 64GB	AB	353061104144089	vibration -strange noise	US	110
iPhone SE White 64GB	BC	356464107411629	broken button home	US	220
iPhone 11 Red 64GB	A-	353967102753814	not a genuine battery message	US	220
iPhone 11 Red 64GB	A-	353967109158926	Screen message	US	220
iPhone 11 Black 64GB	AB	353976102103433	Screen message	US	220
iPhone 11 Purple 64GB	AB/lcd A+	352905111617274	not a genuine display message	US	220
iPhone 11 Red 64GB	AB	352989117161768	not a genuine display message	EU	220
iPhone 11 White 64GB	A+A	352509585109006	Cannot be activated	EU	220
iPhone 11 Red 64GB	AB/A+	352903113197163	No Face ID/screen message	US	220
iPhone 11 Black 64GB	AB	353978107705899	No Face ID/blue spot on screen	US	220
iPhone 11 White 64GB	AB/A+	353969104476667	Stain on the screen	US	220
iPhone 11 White 64GB	A-	353974108207530	Grren spot on the screen	US	220
iPhone 11 Red 64GB	AB	356547103406302	Line on the screen	US	220
iPhone 11 Green 64GB	AB/Lcd A+	352912114129729	Face ID,black camaras,screen message	US	220
iPhone 11 Purple 64GB	AB	353977107764997	Green spot on screen	US	220
iPhone 11 Black 64GB	AB/lcd A+	354000108150014	when the screen is black there is white spot	EU	220
iPhone 11 Black 64GB	A-	356542103211695	battery message/touch	US	220
iPhone 11 Black 64GB	AB/lcd A+	356807115029496	no face ID/dirty front camera	US	220
iPhone 11 Red 64GB	AB/lcd A+	355608700983878	touch	EU	220
iPhone 11 Red 64GB	AB	353996103136836	touch	EU	220
iPhone 11 Red 64GB	A+/A	352370399751297	blue spots on the screen	EU	220
iPhone 11 Black 64GB	A-	352989118906401	reboots	EU	220
iPhone 11 Green 64GB	AB	356550106345212	Black screen, broken LCD	US	220
iPhone 11 White 64GB	AB/Lcd A+	356555104109601	Rear camera broken glass,display message	US	220
iPhone 11 Purple 64GB	AB/Lcd A+	353981104138551	Black screen	US	220
iPhone 11 Black 64GB	AB/Lcd A+	353981100374903	Rear camera broken glass,line lcd,displey message,no slot	US	220
iPhone 11 Green 64GB	A-	352897111782507	Black screen	US	220
iPhone 11 Black 64GB	AB/Lcd A+	356560103716000	Black screen	US	220
iPhone 11 Red 64GB	A-	356553103084636	Black screen	US	220
iPhone 11 White 64GB	A-	356561105385612	Bulge on the scrren,black scrren	US	220
iPhone 11 Purple 64GB	AB	356550109897177	Black screen	US	220
iPhone 11 Purple 64GB	AB/Lcd A+	356555105540788	Touch	US	220
iPhone 11 Purple 64GB	A-	353981108465422	Message screen,battery,no slot,no Face ID	US	220
iPhone 11 Red 64GB	AB	356557105711559	Broken screen	US	220
iPhone 11 White 64GB	A-	353982104043346	Rear camera broken glass,battery message	US	220
iPhone 11 Yellow 64GB	AB/Lcd A+	353978102640000	rear camera broken glass,battery message	US	258,5

iPhone 11 Red 128GB	A-	359130337368551	It reboots	EU	258,5
iPhone 11 Green 128GB	A-	352370394669056	It reboots	EU	258,5
iPhone 11 Purple 128GB	A+/A	351039497003080	Photo gallery flashes	EU	258,5
iPhone 11 Red 128GB	A+/A	359245674232952	Voice message	EU	258,5
iPhone 11 Green 128GB	A-	358981870318416	Earpiece-no sound	EU	258,5
iPhone 11 Black 128GB	A+/A	355608704145201	reboots	EU	258,5
iPhone 11 White 128GB	A+/A	353984109082733	does not turn on	US	258,5
iPhone 11 PURPLE 128 GB	AB	352916119246636	MUTE BUTTOM	EU	258,5
iPhone 11 Purple 128GB	AB	352672766341077	no IMEI	EU	258,5
iPhone 11 Purple 128 GB	AB/lcd A+	352925117389231	noise on cameras	EU	258,5
iPhone 11 White 128GB	AB	353980103069007	reboots/both cameras freeze	US	258,5
iPhone 11 White 128GB	AB	352990114520485	reboots	EU	258,5
iPhone 11 Black 128GB	BC	353988103556162	Does not charge,no Face ID,message display	US	258,5
iPhone 11 Purple 128GB	A+/A	356571109211201	Message battery,message display	US	258,5
iPhone 11 Green 128GB	A+/A	353988109420017	touch	EU	258,5
iPhone 11 Black 128GB	AB	353980105919530	Broken backglass	US	258,5
iPhone 11 Purple 128GB	A-	353993103656392	Touch	US	258,5
iPhone 11 Red 128GB	AB	356551102700236	Line on the screen	US	258,5
iPhone 11 Red 128GB	A+/A	356552109400861	screen flickers	US	258,5
iPhone 11 Yellow 128GB	A+/A	353989100641551	Screen with image	EU	258,5
iPhone 11 BLACK 128 GB	A+/A	356575109799735	FACE ID	EU	280,5
iPhone 11 White 256GB	AB	353987100902106	Important battery message	US	280,5
iPhone 11 Red 256GB	AB/Lcd A+	356556108176307	Pink spots on the screen	US	308
iPhone 11 Pro Silver 64GB	AB/lcd A+	353834107871035	not a genuine display message	EU	308
iPhone 11 Pro Midniht 64GB	A+/A	352832114174709	Face ID	EU	308
iPhone 11 Pro Midniht 64GB	A+/A	352826111192334	Face ID	EU	308
iPhone 11 Pro Space Gray 64GB	A-	353834102074726	?¿	EU	308
iPhone 11 Pro Space Gray 64GB	A+/A	353836106504095	pink display	EU	341
iPhone 11 Pro Silver 256GB	AB	353831105356365	Does not charge,message battery	EU	341
iPhone 11 Pro Midniht Green 256GB	A+/A	353829100292007	Battery message,black front camera	EU	341
iPhone 11 Pro Midnight Green 256GB	A+/A	353842102983630	black spot on the screen	EU	341
iPhone 11 Pro MIDNIGHT GREEN 256GB	A+/A	353236103692292	FACE ID + SCREEN MESSAGE (no original)	US	341
iPhone 11 Pro Midniht Green 256GB	A+A	353842100601887	Black screen,no Face ID	US	341
iPhone 11 Pro Space Gray 256GB	A+A	353833100171880	Battery message/rear camera broken glass	US	341
iPhone 11 Pro Gold 256GB	AB/Lcd A+	353840100708546	Black screen	US	341
iPhone 11 Pro Green 256GB	A-	353841106964513	does not turn on	US	368,5
iPhone 11 Pro Midniht 512GB	A+/A	353827103508429	Strange noise vibration	EU	319
GB	A+/A	352861112008254	THE CAMERA FREEZES	EU	319
iPhone 11 Pro Max SILVER GREY 64 GB	AB/LCD A+	352871111836886	vibrates and black	EU	319
iPhone 11 Pro Max Midnight Green 64GB	A-	352871110961453	reboots	EU	319
iPhone 11 Pro Max Midniht Green 64GB	AB	353909101984883	Black spot on the screen	EU	319
iPhone 11 Pro Max Midniht Green 64GB	AB/Lcd A+	353911105993811	Broken backglass	EU	319
iPhone 11 Pro Max Space Gray 64GB	A-	352869110110345	blue spot on the LCD	EU	319
iPhone 11 Pro Max Silver 64GB	AB	353897109737397	broken display	US	363
iPhone 11 Pro Max Space Gray 256GB	A+/A	353921105134522	Face ID,proximity sensor	EU	363
iPhone 11 Pro Max Midniht Green 256GB	A-	353924109745269	Ghost display	EU	363
iPhone 11 Pro Max Space Gray 256GB	AB	352866112952120	Ghost display	EU	363
iPhone 11 Pro Max Gold 256GB	BC	353908102137301	Display message	EU	352
iPhone 12 Blue 64GB	AB	350342020454031	Face ID	US	352

iPhone 12 Blue 64GB	AB	351166895637308	Face ID	US	352
iPhone 12 Green 64GB	A+/A	353253182679272	Face id	US	352
iPhone 12 Blue 64GB	A-	357676154513358	no Face ID	EU	352
iPhone 12 Blue 64GB	A+/A	359824133382887	earpiece-no sound	US	352
iPhone 12 Black 64GB	A-	353253180185363	No service	US	352
iPhone 12 Black 64GB	A-	352243616562369	does not turn on	US	352
iPhone 12 Green 64GB	A+/A	357814431979080	wi fi	US	352
iPhone 12 Black 64GB	A+/A	352590376411769	no service	US	352
iPhone 12 Green 64GB	A+/A	352045135785458	reboots	EU	352
iPhone 12 White 64GB	A+/A	357078168600398	voice notes	EU	352
iPhone 12 Purple 64GB	A+/A	354112729308465	microphone-strange noise	EU	352
iPhone 12 Blue 64GB	A+/A	355541825653334	does not turn on	US	352
iPhone 12 Red 64GB	A+/A	359827480456576	voice notes- no sound	EU	352
iPhone 12 Blue 64GB	AB/Lcd A+	359669600779697	Does not read sim	US	352
iPhone 12 Blue 64GB	A+/A	359669607328431	Not charge	US	352
iPhone 12 Blue 64GB	AB/Lcd A+	352590379863982	Does not read sim	US	352
iPhone 12 Blue 64GB	A+/A	357504277061503	Restart	US	352
iPhone 12 Blue 64GB	A+/A	350197049752900	Restart	US	352
iPhone 12 Green 64GB	A+/A	357463522427938	anything	US	352
iPhone 12 Black 64GB	A+/A	353509873055043	call error	US	352
iPhone 12 Red 64GB	AB	353509871624329	bluetooth does not work/wi-wi does not work	US	352
iPhone 12 BLUE 64GB	A-	359669603666362	BENT CHASIS	US	352
iPhone 12 Black 64GB	AB	355727330079053	no service	US	352
iPhone 12 Red 64GB	A+A	352619279849153	It reboots	EU	352
iPhone 12 Green 64GB	A+/A	353361735339540	no service	EU	352
iPhone 12 Blue 64GB	A+/A	353509878537391	front camera does not work	US	352
iPhone 12 Black 64GB	BC	353044111897360	Rear camera does not focus	US	352
iPhone 12 White 64GB	A+A	357076838825320	Green stripe on screen	EU	352
iPhone 12 Black 64GB	A+/A	353253189093865	does not turn on	US	352
iPhone 12 White 64GB	A+/A	359458689308937	reboots	EU	352
iPhone 12 Blue 64GB	A+/A	353253188467482	black rear camera+no flash	US	352
iPhone 12 Black 64GB	A+/A	353039110371557	black rear camera	US	352
iPhone 12 Black 64GB	AB	353042112892026	does not turn on	US	352
iPhone 12 Green 64 GB	AB/Lcd A+	353040112246144	Battery message,earpiece-no sound	US	352
iPhone 12 Black 64 GB	AB	359824135658045	Broken screen/no slot	US	352
iPhone 12 White 64 GB	AB	356599140784464	Cracked screen	US	352
iPhone 12 Blue 64GB	A+/A	359824133188714	Rear camera is blocked	US	352
iPhone 12 Blue 64GB	A+/A	350765871559708	Face ID,black cameras	US	352
iPhone 12 Blue 64GB	A+/A	359824133444059	Touch	US	352
iPhone 12 Blue 64GB	A+/A	351156781047340	Black rear camera	US	352
iPhone 12 Blue 64GB	AB/Lcd A+	353038110231399	Black camera	US	352
iPhone 12 Blue 64GB	A-	359824130744220	Black camera	US	352
iPhone 12 Green 64GB	AB	356609239319658	Cracked screen	EU	352
iPhone 12 Green 64GB	AB	350839221455089	Broquen display	US	352
iPhone 12 Green 64GB	AB	353038116533020	Black spot on screen	US	352
iPhone 12 Black 64GB	AB/Lcd A+	357463523405438	Black rear camera	us	352
iPhone 12 Black 64GB	A+/A	350839226289079	Black spot on the screen	US	352
iPhone 12 Black 64GB	AB/Lcd A+	359669600208655	Touch	US	352
iPhone 12 Purple 64GB	A+/A	352377990858009	green lines on the screen	EU	352

iPhone 12 Blue 64GB	A-	359676577541331	rear camera shakes	EU	352
iPhone 12 Red 64GB	AB	353055116636066	yellow spot on the screen/overheat	EU	352
iPhone 12 Red 64GB	AB	359827480315780	rear camera shakes	EU	352
iPhone 12 Black 64GB	AB/Lcd A+	350197040164683	Broken backglass	US	352
iPhone 12 Black 64GB	A+A	352377993001490	Green line on the screen	EU	352
iPhone 12 Blue 64GB	AB/Lcd A+	353039112505384	Cracked screen	US	352
iPhone 12 Blue 64GB	AB/Lcd A+	359669603200022	Broken screen	US	352
iPhone 12 White 64GB	A+A	353050114704974	Pink line on the screen	US	352
iPhone 12 BLUE 64GB	A+/A	351793397555447	MICROPHONE	US	352
iPhone 12 Black 64GB	AB	353041110060339	microphone/bad colors on screen	US	352
iPhone 12 Red 64GB	A+/A	353041113839788	Cracked screen	US	352
iPhone 12 Black 64GB	A-	356599144947687	Screen flickers ,,parpadella,,	US	352
iPhone 12 BLUE 64GB	A+/A	351183323164003	WI-FI	US	352
iPhone 12 BLUE 64GB	AB/LCD A+	355044562587062	BROKEN CHASIS (BACK PART)	US	352
iPhone 12 Blue 64GB	AB	353054114915721	screen with strange pixels	EU	352
iPhone 12 Black 64GB	AB	353043113520525	Camera message	US	390,5
iPhone 12 Blue 128GB	AB/Lcd A+	351183324020386	camera message	US	390,5
iPhone 12 White 128GB	A-	353043119498635	No imei	US	390,5
iPhone 12 White 128GB	AB/Lcd A+	353043110482570	earphone-no sound	US	390,5
iPhone 12 Blue 128GB	A+/A	357771576599406	reboots	EU	390,5
iPhone 12 Blue 128GB	AB	351601280809294	reboots	US	390,5
iPhone 12 White 128GB	A+/A	357463524371134	reboots	US	390,5
iPhone 12 WHITE 128GB	A+/A	359195672641177	CALL WITHOUT SOUND	EU	390,5
iPhone 12 Blue 128GB	AB	352243611874744	constantly reboots	US	390,5
iPhone 12 Blue 128GB	AB	350197045098803	black spots on the LCD	US	390,5
iPhone 12 White 128GB	A-	355541825128204	black LCD	US	390,5
iPhone 12 Blue 128GB	AB	353490232712899	front camera freeze/reboots	EU	390,5
iPhone 12 Black 128GB	AB	353043112885085	Broken screen/no slot	US	390,5
iPhone 12 Green 128GB	A+A	355541829964844	Touch	US	390,5
iPhone 12 Blue 128GB	AB	359824130250004	wi-fi does not work	US	390,5
iPhone 12 BLUE 128GB	AB	359827486752929	REBOOT	EU	390,5
iPhone 12 BLACK 128GB	A+/A	359827481945973	RESTART	EU	390,5
iPhone 12 Black 128GB	AB	350342022983367	damaged screen	US	390,5
iPhone 12 Black 128GB	A-	353503756295651	bent device/wi fi does not work	US	390,5
iPhone 12 Green 128GB	AB	351156787273973	wi-fi does not work	US	390,5
iPhone 12 Blue 128GB	AB	350197041815325	through mobile data	US	390,5
iPhone 12 Black 128GB	A-	353039115368244	red line on the LCD	US	390,5
iPhone 12 White 128GB	AB	353044115942220	touchscreen does not work	US	390,5
iPhone 12 Blue 128GB	AB	356122160585214	camera flickers	EU	390,5
iPhone 12 Black 128GB	A+/A	357676154596916	screen turns pink	EU	390,5
iPhone 12 Blue 128GB	AB	351066252094038	reboots	EU	440
iPhone 12 Pro Graphite 128GB	BC	353147476333408	Face ID	US	440
iPhone 12 Pro Pacific Blue 128GB	BC	356961130733564	Face ID	US	440
iPhone 12 Pro Pacific Blue 128GB	BC	354121935622908	screen message	EU	440
iPhone 12 Pro Gold 128GB	AB	356695117459799	No imei	EU	440
iPhone 12 Pro GRAPHITE 128GB	A-	353076691412087	REBOOT - GETS FROZEN	EU	440
iPhone 12 Pro Pacific Blue 128GB	AB	356692116393335	reboots	EU	440
iPhone 12 Pro Graphite 128GB	AB	356696111013616	can't be activated	EU	440
iPhone 12 Pro Gold 128GB	AB	350320092083367	Face ID does not work	EU	440

